


Titan Profile



Inclination



1. Hold lens fixation firmly

2. Cover hinge closely and adjust inclination into requested direction on titanium side part




Temple Opening

REDUCE




ENLARGE





Temple Disassembly




- 1. Hold lens fixation firmly
- 2. Close temple by 45°

- Press cylinder out of SNAP-hinge.
 Apply pressure right beside hinge.
 ATTENTION: Never hand temple
- 4. ATTENTION: Never bend temple




Temple Assembly





Temple Curving



Curve temple in large movements. Do not bend!