





COLORAMA Instructions: *Disassembly, Mounting and Inclination of Temple*

1. DISASSEMBLING THE TEMPLE



With the temple closed, grip the eyewear firmly at the BLS with thumb and index finger. Press down on the temple on either side of the hinge, and the temple will become unfastened with a click. Remove the temple.

2. MOUNTING THE TEMPLE



Put the temple on a safe edge of a table. Place the side part exactly at the opening of the plastic temple and press it in.

3. TEMPLE INCLINATION



Hold side parts very firmly with the universal mounting pliers close to the area of the lens fixation. Inclinate the side parts with flat pliers. NOTE: Only bend metal parts, never plastic.