


ADJUSTMENT INSTRUCTION

TITAN EDGE

1. DETACH TEMPLE

- Position round stick (diameter 5 mm/0.196 inch) close to hinge (pic. 1 and 2)
- Fold the temple and press together with thumb














TITAN EDGE


2. INCLINATE TEMPLE

- Fix trim with assembly pliers (pic. 1)
- Bend metal hinge with flat pliers (pic 2)
- Fasten temple again

0







TITAN EDGE