


Titan Elements



INCLINATION




- 1. Hold the frame at the lens fixation point.
- 2. Hold hinge firmly, and apply pressure to the side part, gently moving it in the desired direction.



TEMPLE OPENING


REDUCE ENLARGE





TEMPLE DISASSEMBLY






- 1. Hold the lens fixation point firm.
- 2. Close temple halfway.

3. Gently press cylinder out of the loop of the SNAP-hinge, by applying pressure close to the cylinder. WARNING: Do not bend the temple!



TEMPLE END DISASSEMBLY






Apply pressure at the temple ends with flat nylon pliers, about 2 centimeters in from the metal temple. Repeat this on the four sides of the temple end, so that the glue inside comes loose. You may hear it break free from the glue. Afterwards pull off the temple end.

NOTE: Due to the frame design, the temple cannot be shortened.



TEMPLE CURVING



By hand, curve the temple end in gradual movements. Be sure not to forcefully bend the temple.