



Vivid Sky Technical Instructions

Models 1613, 1614, 2956, 2957

V-Bevel Edging

Vivid Sky | Glazing with 100% Silhouette Panorama Lenses

Silhouette now offers premium prescription lenses for all Silhouette frames.

Expertly crafted in Austria using our exclusive Panorama® lens designs, 100% Silhouette is the perfect unity of lenses, frames and service.

This results in a 100% Silhouette eyewear solution that offers the wearer exceptional visual comfort and edge to edge clarity.

For more information visit:

<https://www.silhouette.com/us/us/vision-sensation>,
scan the QR code or contact your Silhouette Account Executive



Scan QR code to visit 100%
Silhouette website



Glazing | Vivid Sky

Frame is designed with a 5.0 base curve, however other base curves will work

Lenses with base curves flatter than 5.0 should have V-bevel cut to match 5.0 base curve

Recommended lenses are High Index 1.6, 1.67, Polycarbonate and Trivex

OMA shape files available at

<https://portal.silhouette.com>

Cold glazing only! Do not heat front to aid in lens insertion or removal!



Lens Removal | Vivid Sky



1. Partially pull the top frame rim up
2. Push the lens forward out of the rim

Lens Insertion | Vivid Sky



1. Insert lens from the rear, starting with nasal corner
2. Continue inserting the lens along top to temporal corner
3. Continue around the lens circumference until the lens snaps into place.

Inclination | Vivid Sky



1. Open the temple fully
2. Support hinge area as shown above and bend at hinge to desired angle
3. Do not change inclination more then +/- 5 degrees

Temple Opening Increase | Vivid Sky



Open the temple and push it outside with your thumb and index finger

Temple Opening Decrease | Vivid Sky



Open the temple and push endpiece inward with your thumb and index finger

Temple Removal | Vivid Sky



1. Close the temple fully and grab temple with fingers



2. Pull off the temple off hinge in direction of red arrow

Temple Assembling | Vivid Sky



1. With temple in position shown above, align temple with hinge fingers



2. Press the temple onto hinge in direction of red arrow

Nosepad adjustment | Vivid Sky



Adjust nosepads with the narrower slot (circled) on the Blue Multi-Tool in the desired direction

Temple Shortening | Vivid Sky



Vivid Sky temples cannot be shortened

Other temple lengths available: 1613 / 1614 - 135 mm, 140 mm

2956 / 2957 - 140 mm, 145 mm

Temple-end adjustment | Vivid Sky



1. Adjust temple ear bend in large radius to avoid kinking the temple cover
2. Do not apply pressure to the temple tip when adjusting.

Teflon Lubricant | Vivid Sky



After cleaning the frame in an ultrasonic bath
relubricate the hinge with Silhouette Teflon lubricant.

Additional Information | Vivid Sky

Cleaning in an ultrasonic bath or with ethanol/ spirit is possible.
Avoid high temperatures such as the dashboard in the car or the sauna.

Always use the supplied case for storage.

